



60's TELECASTER 0131600




60's TELECASTER 0131600

CONTROL ASSEMBLY



BRIDGE ASSEMBLY



60's TELECASTER 0131600

| REF.# | P/N | DESCRIPTION |
|-------|------------|------------------------------|
| 1 | 0058381000 | Neck, 60's Telecaster R/W |
| 2 | 0047912000 | Tuning Key, (1) Set |
| | 0053020000 | Bushing, Key |
| | 0011357000 | Mounting Screw |
| 3 | 0083675000 | Bone Nut |
| 4 | 0010389000 | String Retainer |
| | 0020423000 | Sapcer |
| | 0011358000 | Mounting Screw |
| 5 | 0012252000 | Truss Rod Adjustment Nut |
| 6 | 0058380XXX | Body, 60's Telecaster, Alder |
| 7 | 0018353000 | Neck Mounting Plate |
| | 0015636000 | Mounting Screw |
| 8 | 0012344000 | Strap Button |
| | 0015610000 | Mounting Screw |
| 9 | 0056077000 | Pickguard, Tele, Aged White |
| | 0015578000 | Mounting Screw |
| 10 | 0053678000 | Pickup, Neck |
| | 0016295000 | Mounting Screw |
| | 0039410000 | Tubing, Latex Cut |
| 11 | 0055216000 | Pickup, Bridge |
| | 0015800000 | Mounting Screw |
| | 0036878000 | Tubing, Latex Cut |
| 12 | 0019064000 | Control, 250k (2) |
| | 0016352000 | Mounting Hex Nut |
| | 0016436000 | Washer, Lock Intl. |
| 13 | 0013359000 | Knob, Knurled Chrome (2) |
| | 0028897001 | Screw Set (2) |
| 14 | 0040778000 | Plate, Control |
| | 0016188000 | Mounting Screw |
| 15 | 0053290000 | Switch, Lever 3-Position |
| | 0019448000 | Knob, Black |
| | 0021413000 | Mounting Screw |
| 16 | 0015552000 | Capacitor, .05uF |
| 17 | 0047329000 | Output Jack |
| | 0016352000 | Mounting Hex Nut |
| | 0016436000 | Washer, Lock Intl. |
| 18 | 0021452000 | Ferrule, Jack |
| | 0010355000 | Retainer, Jack |
| | 0016352000 | Mounting Hex Nut |
| 19 | 0058384000 | Bridge Assy |
| | 0016188000 | Mounting Screw |
| 20 | 0054162000 | Bridge Plate |
| 21 | 0056038000 | Bridge Section, (3) |
| 22 | 0015834000 | Intonation Screw, (3) |
| | 0018689000 | Intonation Spring, 1-3 |
| 23 | 0016105000 | Height Adjust Screw, (6) |
| 24 | 0012112000 | String Retainer, Ferrule |

Body Part Number

| | |
|------------|-----------------|
| 0058380505 | Olympic White |
| 0058380506 | Black |
| 0058380509 | Candy Apple Red |

60's TELECASTER 0131600
SWITCH & CONTROL FUNCTION

