



'MUDDY WATERS TELECASTER 0138500




'MUDDY WATERS TELECASTER 0138500

CONTROL ASSEMBLY



BRIDGE ASSEMBLY




'MUDDY WATERS TELECASTER 0138500

REF.#	P/N	DESCRIPTION
1	0058012000	Neck, Mexico, Muddy Waters Telecaster, M/N
2	0047912000	Tuning Key, (1) Set
	0011357000	Mounting Screw
	0053020000	Bushing
3	0083675000	Bone Nut
4	0010389000	String Retainer
	0011357000	Mounting Screw
5	0012252000	Truss Rod Adjustment Nut
6	0054161xxx	Body, '50 Tele., Ash Paint
7	0058041000	Neck Mounting Plate
	0015636000	Mounting Screw
8	0012344000	Strap Button
	0015610000	Mounting Screw
9	0058016000	Pickguard, Muddy Waters Tele, White
	0015578000	Mounting Screw
10	0018483000	Pickup, Neck, Vintage Tele
	0016295000	Mounting Screw
	0039410000	Tubing, Latex Cut
11	0058014000	Pickup, Bridge, Muddy Waters, Tele
	0015800000	Mounting Screw
	0036878000	Tubing, Latex Cut
12	0019064000	Control, 250K, Audio (2)
	0016352000	Mounting Hex Nut
	0016436000	Lock Washer, Intl
13	0024604000	Knob, Black W/White Stamp 1-10, (2)
14	0040778060	Control Plate
	0015578000	Mounting Screw
15	0053290000	Switch, Lever 3-Position
	0015800000	Mounting Screw
	0056042000	Knob, Black
16	0015552000	Capacitor, .05uf
17	0047329000	Output Jack
	0016352000	Mounting Hex Nut
	0016436000	Lock Washer, Intl
	0010355060	Retainer, Jack
18	0021452000	Jack Ferrule
19	0058011000	Bridge Assembly, Muddy Waters Tele
	0016188000	Mounting Screw
20	0054162000	Bridge Plate
21	0018360000	Bridge Section, (3)
22	0015834000	Intonation Screw, (3)
	0018689000	Intonation Spring, (3)
23	0016105000	Height Adjustment Screw, (6)
24	0012112000	String Retainer Ferrule

Body Part Number	
0054161509	Candy Apple Red

'MUDDY WATERS TELECASTER 0138500

SWITCH & CONTROL FUNCTION



3 WAY SWITCH POSITION			
			← 3 WAY SWITCH POSITION
MT	MT	MT	← TONE CONTROL
			← NECK PICKUP
			← BRIDGE PICKUP
	PICKUP IS ON		PICKUP IS OFF

