


# VARIOUS STANDARD WIRING DIAGRAMS #2




## STANDARD WIRING FOR SINGLE COIL PHASING

S-100 / S-150 = out of production  
 Transensor  
 Lace Sensor




## STANDARD WIRING FOR HUMBUCKER PHASING

D -100  
 D -150  
 Transensor  
 Lace Sensor



## STANDARD WIRING FOR HUMBUCKER SERIES / PARELLEL - OR - SERIES / SPLIT / PARELLEL

D -100  
 D -150  
 Transensor  
 Lace Sensor



## STANDARD WIRING FOR HUMBUCKER SERIES / SPLIT / PHASED WITH ITSELF

D -100  
 D -150  
 Transensor  
 Lace Sensor

