DWG.No. JTM6-60-02

BLOCK DIAGRAM FOR SERVICE REFERENCE ONLY

JS2 · V101 · VR1 · RL1 · TR201 · TR202 · JS203 · JS204 · JS205 · V103 · VR2 VR3 VR4 · VR5 · V102 · JS206 · IC4 · VR10 · IC1 · REVERB · IC2 · IC3 · VR11 · VR12 · VR7 VR8 VR9 · VR6 · IC5 · SW201 · XLR201 · V104 · V105 · V106 · JS202 · JS201 · OUTPUT TX · CN201 · VR201 · VR13

POWER PCB CIRCUIT DIAGRAM JTM6-61-02

TO CN105 · CN12 · F1 · F2 · D3 D5 D2 D4 1N4007 · +20V · TO RELAY CCT · REG1 · REG2 · +15V · -15V · IC1a · IC5a · IC2a · IC4a · CN10 TO CN205

MAINS/OUTPUT PCB CIRCUIT DIAGRAM JTM6-62-02

IC5b · IC5c · IC5e · IC5d · TO CN202 · CN11

CN101 TO CN1 · CN102 TO CN2 · CN106 TO CN3 · CN107 TO CN4 · CN108 TO CN5 · CN203 TO CN6 · INPUT · JS2 · GN · TO POWER AMP PCB CIRCUIT DIAG JTM6-61-02 GRID REF D 5

W1 TO W110 POWER PCB CIRCUIT DIAGRAM JTM6-61-02 · W3 TO W111 POWER PCB CIRCUIT DIAGRAM JTM6-61-02 · W101 TO W2 · VR1 · VR2 · VR3 · VR4 · VR5 · VR6 · VR7 · VR8 · VR9 · VR13 · RL1a · RL1b · RL1c · RL2a · RL2b · RL2c · CN8 TO CN103 · POWER PCB CIRCUIT DIAGRAM JTM6-61-02

MAINS/OUTPUT PCB CIRCUIT DIAGRAM JTM6-62-02 CN206 TO CN9 · CN7 TO CN110 · POWER PCB CIRCUIT DIAGRAM JTM6-61-02 · TO W119 · POWER PCB CIRCUIT DIAGRAM JTM6-61-02

IC3e · IC3b · IC3c · IC3d · IC4b · IC2b · IC3 · REVERB SEND PH2 BLACK PHONO · REVERB · REVERB RETURN PH1 RED PHONO · TO REG1 CCT +20V · TR1 · TR2 · TR3 · D6 · D1 · JS1 FOOTSWITCH · PANEL SWITCH · SW1a · SW1b · LED1 BI LED

NOTE :-
RELAYS MUST BE FUJITSU TYPE 47 ONLY

R21 C27 C45 & C46 NOT FITTED

ISS	ECO NUMBER	DATE	ALL OTHER HOLES •	X = (THROUGH PLATED)
4	1215	28-6-96	A E J N	
3	1114		B F K P	
2	1040	16/11/95	C G L Q	MATERIAL THICKNESS: RSB 04/05/95
1		04/05/95	D H M R	DRAWN: JS 2-7-96

Marshall

© JIM MARSHALL (PRODUCTS) LTD.
DENBIGH ROAD, BLETCHLEY, MILTON KEYNES, MK1 1DG.
TEL (0908)375411 FAX (0908)376118

MODEL: JTM60

TITLE: PRE-AMP PCB CIRCUIT DIAGRAM

DWG.No: JTM6-60-02 · ISS: 4